

UAE Email: mathews@generaltechuae.com Tel : +971 (0) 2 550 7702 Fax : +971 (0) 2 550 7706

SAUDI Mathews@generaltechsaudi.com Tel : +966 (0) 3 834 4264 Fax : +966 3 834 4538

Gagemaker FSR-37 | Frame Setting Master for R-37 & RX-37 groove

For the gauges in the BX and BXG Series, the precision ground setting standards are the R & RX face groove and hole location setting masters. Because each standard is built on a particular groove, it can be used to calibrate both BX and BXG gauges.

Specifications Details